

CO₂ Wine preserver



Start with a bicycle tire inflator. Shrink Schrader valve ball inflators to each end of a 6 inch piece of shrink tubing. Attach one end to the inflator output; attach the other end to a Schrader valve cap that has two 15 mil holes drilled in it. Insert a food grade CO₂ cartridge.



Insert the nozzle a couple of inches into a partially empty bottle of wine. Give it a 1 or 2 second burst and then cork the bottle. Prevents oxidation and adds a smidgen of effervescence.